



MODEL 615 AND 616 RADIATION DAMPER FUSIBLE LINK INSTALLATION

1. FUSIBLE LINK COMES TAPED TO BLADE.



2. CLOSE BUTTERFLY DAMPER.



3. HOOK ONE END OF THE FUSIBLE LINK TO THE ROUND CLIP ON THE BLADE.



4. FINISH BY HOOKING THE OTHER END OF THE FUSIBLE LINK THE TO STRAIGHT CLIP FROM THE OPPOSITE BLADE.

